


If the foot section of the bed does not go flat after pressing the flat button on the remote control, it can be adjusted by turning the turnbuckle clockwise to raise the foot section or anticlockwise to lower the foot section. The turnbuckle is located on the foot leveler (See figure 9).



Adjustable Base # TCZ04R5Z Wireless



Owner's Manual

INNOVA™

SLEEP SYSTEMS

CONTENTS

Advisory

Setup and Installation

Wireless Hand Control

1-2-20 year Warranty

